HOW TO ADJUST THE SIZE OF THE DATE WRISTBAND

PINHEAD

PIN

1

Unscrew the pinhead from the right side of the link. You may need a second screwdriver to hold the other end tight to prevent it from moving.

2

After removing the pinhead, insert the screwdrive and push all the way through to remove the pin.

3

Done